

# TR5/TR6 Drum Trolleys

## INSTRUCTION MANUAL

### Introduction

Thank you for purchasing either a Macnaught TR5 or TR6 Drum Trolley. The TR5 trolley has been designed to suit 20 kg containers and the TR6 trolley is designed to suit 55kg containers.

### TR6 55Kg Trolley


Replacement parts			
Item No	No. Req	Part or Set	Part Name
1	1	n/a - new trolley required	Trolley Base
2	4	n/a N630s	Thumbscrew s
3	4		Castor
4	4		Hex Nut 3/8" UNC
5	8		Washer 3/8"

### TR5 20Kg Trolley

Replacement parts			
Item No	No. Req	Part or Set	Part Name
1	1	n/a - new trolley required	Trolley Base
2	4	n/a N630s	Thumbscrew s
3	4		Castor
4	4		Hex Nut 3/8" UNC
5	8		Washer 3/8"



Note:- If fitting a new set of replacement castors to a trolley manufactured before August 2002 you will be required to drill out the castor holes in the trolley base with a 3/8" diameter drill.



Macnaught Pty Limited  
ABN 66 000 075 785

41-49 Henderson Street  
Turrella NSW 2205 Sydney Australia  
Postal Address PO Box 90  
Amcliffe NSW 2205 Sydney Australia

T: +61 2 9567 0401  
F: +61 2 9597 7773  
W: [www.macnaught.com.au](http://www.macnaught.com.au)

For Warranty Terms and Conditions see [macnaught.com.au](http://macnaught.com.au)  
For a list of Australian Service Centres see [macnaught.com.au](http://macnaught.com.au)